

MAINTENANCE INFORMATION

Article Text

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

ARTICLE BEGINNING

1990-94 MAINTENANCE

Volkswagen Maintenance Information

Corrado G60 (1990-92)

SLC (1992-94 USA)

VR6 (1992-94 Canada)

* PLEASE READ THIS FIRST *

NOTE: For scheduled maintenance intervals and the related fluid capacities, fluid specifications and labor times for major service intervals, see SCHEDULED SERVICES article in this section. Warranty information and specifications for fluid capacities, lubrication specifications, wheel and tire size, and battery type are covered in this article.

MODEL IDENTIFICATION

VIN LOCATION

The Vehicle Identification Number (VIN) is located on the left side of the dash panel at the base of the windshield. The VIN chart explains the code characters.

VIN CODE ID EXPLANATION

Numbers preceding the explanations in the legend below refer to the sequence of characters as listed on VIN identification label. See VIN example below.

UAAA;
3 (VIN) W V W A B 0 5 3 2 M H 0 9 9 7 1 7 3
3 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 3
AAU

1 - Manufacturing Country

W * Germany
1 * United States
3 * Mexico
9 * Brazil

2-3 - Manufacturer

VW * Volkswagen

4 - Series

D * 2-Door G60 (1990-92)
E * 2-Door SLC (1992-94 USA)
E * 2-Door VR6 (1992-94 Canada)

MAINTENANCE INFORMATION

Article Text (p. 2)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

5 - Engine

- B * 1.8L 4-Cyl. G-60 Supercharged Digifant FI, 158 HP (1990-92)
- D * 2.8L V6 Motronic M2.9 FI, 172 HP (1992-93)
- F * 2.8L V6 Motronic SFI, 172 HP (1994)

6 - Restraint System

- 4 * Electric Passive With Manual Lap

7-8 - Model

- 50 * Corrado

9 - VIN Check Digit

- 2 * Computer Selected Check Number

10 - Vehicle Model Year

- L * 1990
- M * 1991
- N * 1992
- P * 1993
- R * 1994

11 - Assembly Plant

- A * Ingolstadt
- B * Brussel
- E * Emden
- G * Graz
- H * Hannover
- K * Osnabruk
- M * Mexico
- N * Neckarsulm
- P * Brazil
- S * Stuttgart
- W * Wolfsburg

12-17 - Serial Number

- * Sequential Production Number

MAINTENANCE SERVICE INFORMATION

SEVERE & NORMAL SERVICE DEFINITIONS

NOTE: Use the Severe Service schedule if the vehicle to be serviced is operated under ANY (one or more) of these conditions:

Service is recommended at mileage intervals based on vehicle operation. Service schedules are based on the following primary operating conditions:

Normal Service

- * Driven More Than 10 Miles Daily
- * No Operating Conditions From Severe Service Schedule

MAINTENANCE INFORMATION

Article Text (p. 3)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

Severe Service (Unique Driving Conditions)

- * Short Trips In Freezing Temperatures
- * Towing Or Heavily Loaded
- * Severe Dust Conditions
- * Hot Weather, Stop-And-Go Driving
- * Extensive Idling

CAMSHAFT TIMING BELT

CAUTION: Failure to replace a faulty camshaft timing belt may result in serious engine damage.

The condition of camshaft drive belts should always be checked on vehicles which have more than 50,000 miles. Although some manufacturers do not recommend belt replacement at a specified mileage, others require it at 60,000-100,000 miles. A camshaft drive belt failure may cause extensive damage to internal engine components on most engines, although some designs do not allow piston-to-valve contact. These designs are often called "Free Wheeling".


Many manufacturers changed their maintenance and warranty schedules in the mid-1980's to reflect timing belt inspection and/or replacement at 50,000-60,000 miles. Most service interval schedules in this manual reflect these changes.

Belts or components should be inspected and replaced if any of the following conditions exist:

- * Cracks Or Tears In Belt Surface
- * Missing, Damaged, Cracked Or Rounded Teeth
- * Oil Contamination
- * Damaged Or Faulty Tensioners
- * Incorrect Tension Adjustment

Inspect camshaft timing belt condition every 20,000 miles. Replace belt as necessary.

DRIVE BELT ROUTING



93183104

Fig. 1: Drive Belt Tensioner Adjustment (VR6)

Courtesy of Volkswagen United States, Inc.

MAINTENANCE INFORMATION


Article Text (p. 4)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC


Wednesday, March 22, 2000 09:14PM




93H83102

Fig. 2: Drive Belt Routing (VR6)

Courtesy of Volkswagen United States, Inc.



* Arrow = Tensioning point



50H00650

Fig. 3: Drive Belt Routing (Four Cylinder Without A/C)

Courtesy of Volkswagen United States, Inc.

MAINTENANCE INFORMATION


Article Text (p. 5)

1993 Volkswagen Corrado


For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM



* Arrow = Tensioning point



50I00651

Fig. 4: Drive Belt Routing (Four Cylinder With A/C)

Courtesy of Volkswagen United States, Inc.

SERVICE POINT LOCATIONS

MAINTENANCE INFORMATION


Article Text (p. 6)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM



50A11999

Fig. 5: Service Point Locations (1.8L 4-Cylinder)

Courtesy of Volkswagen United States, Inc.

MAINTENANCE INFORMATION


Article Text (p. 7)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM



- 1 - Engine oil dipstick
- 2 - Engine oil filler cap
- 3 - Coolant expansion tank
- 4 - ATF-dipstick*
- 5 - Power steering reservoir
- 6 - Brake fluid reservoir
- 7 - Windshield washer container
- 8 - Battery (protected by a cover)
- 9 - Fuse for coolant-fan after run
(For service use only) **50B11966**

Fig. 6: Service Point Locations (2.8L V6)
Courtesy of Volkswagen United States, Inc.

ADDITIONAL SERVICE INFORMATION

MAINTENANCE INFORMATION

Article Text (p. 8)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

CAMSHAFT TIMING BELT SERVICE




Fig. 7: Aligning 1.8L Timing Marks (8-Valve)
Courtesy of Volkswagen United States, Inc.

NOTE: For more information on camshaft timing belt service refer to the 1.8L 4-CYL 8-VALVE & 2.0L 4-CYL 16-VALVE article in the ENGINE MECHANICAL section.

ATTACHING VAG 1551 SCAN TESTER

MAINTENANCE INFORMATION


Article Text (p. 9)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM



93D80468

Fig. 8: Connecting Scan Tester to Data Link Connector (Corrado)
Courtesy of Volkswagen United States, Inc.

NOTE: For more information on scan tester connections refer to the G - TESTS W/CODES article in the ENGINE PERFORMANCE section.

INFORMATION LABEL LOCATIONS




Fig. 9: Information Label Locations
Courtesy of Volkswagen United States, Inc.

MAINTENANCE INFORMATION

Article Text (p. 10)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

SERVICE LABOR TIMES

SERVICE LABOR TIMES TABLE (HOURS)

APPLICATION										FLUID SPECIFICATIONS									

MAINTENANCE INFORMATION

Article Text (p. 11)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

Application	Quantity (1)
A/C System R-12 Refrigerant	
1990-92 (up to 7/92)	37-40 Ozs.
A/C System R-134a Refrigerant (2)	
1993-94 (from 7/92)	28.2-31.8 Ozs.
Cooling System	
4-Cyl.	6.8 Qts. (6.5L)
V6	9.1 Qts. (8.6L)
Engine Oil (3)	
4-Cyl.	4.3 Qts. (4.0L)
V6	6.3 Qts. (6.0L)
Fuel Tank	
4-Cyl.	14.5 Gals. (55L)
V6	18.5 Gals. (55L)
Automatic Transmission	
Fluid Change	3.2 Qts. (3.0L)
Overhaul	5.9 Qts. (5.6L)
Manual Transmission	2.1 Qts. (2.0L)
Final Drive	
Differential (A/T) (4)	0.8 Qt. (.75L)

- (1) - Capacities are recommended or calculated levels. Always use dipstick (if available) to measure level.
(2) - Use of R-12 in a R134a system will result in SEVERE DAMAGE.
(3) - Includes oil filter change.
(4) - Lifetime fill.

AA

WHEEL & TIRE SPECIFICATIONS

Wheel and tire sizes vary according to vehicle and equipment and can be found on tire information label on each vehicle. Wheel and tire specifications and tire inflation pressures are listed on a label found inside fuel tank flap.

NOTE: Snow chains must be used on drive wheels, in pairs only.

WHEEL TIGHTENING

Tighten all wheel lugs to 80 ft. lbs. (110 N.m).

BATTERY SPECIFICATIONS

CAUTION: When battery is disconnected, vehicles equipped with computers may lose memory data. When battery power is restored, driveability problems may exist on some vehicles. These vehicles may require a relearn procedure. See COMPUTER RELEARN PROCEDURES article in the GENERAL INFORMATION section.

All models use BCI group 41 batteries with cold crank rating

MAINTENANCE INFORMATION

Article Text (p. 12)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

of 650 amps.

CAUTIONS & WARNINGS

CAUTION: Contact with live components of ignition system while engine is running could lead to a fatal electric shock.

CAUTION: Brake pedal requires extreme pressure to stop vehicle when engine is not running.

WARRANTY INFORMATION

CAUTION: Always refer to customer's copy of warranty information for specific model application and/or coverage limitations.

BASIC NEW CAR WARRANTY

Manufacturer warrants to the original retail customer, and any subsequent purchaser, that every vehicle imported and sold as a new vehicle to a retail customer will be free of defects in material and workmanship for 2 years or 24,000 miles, whichever comes first, after date of delivery to the first retail customer, or after vehicle was first placed in service.

LIMITED WARRANTY

Warrants cars to be free of defects in materials or workmanship for a period of 2 years or 24,000 miles, whichever comes first.

LIMITED POWER TRAIN WARRANTY

Covers engine, transmission and drivetrain for a period of 5 years or 50,000 miles, whichever occurs first.

ANTI-CORROSION

Covers holes caused by corrosion in body sheet metal for 6 years, without respect to mileage, so long as inspection and maintenance services are performed.

EMISSION CONTROL SYSTEM

Manufacturer warrants to the initial purchaser and each subsequent purchaser that this vehicle is designed, built, and equipped so as to conform at the time of sale with all U.S. and California Air Resources Board emission regulations applicable at the time of manufacture, and that this vehicle is free from defects in materials and workmanship which cause it to fail to conform with applicable regulations within the first 5 years or 50,000 miles, whichever occurs first.

MAINTENANCE INFORMATION

Article Text (p. 13)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC


Wednesday, March 22, 2000 09:14PM

FUSES & CIRCUIT BREAKERS

FUSE PANEL LOCATION

Fuse panel is located under left side of dash board by driver's knee. Fuses are numbered from left to right.

FUSE PANEL IDENTIFICATION



50D11968

Fig. 10: Fuse & Relay Panel Identification (1990)

Courtesy of Volkswagen United States, Inc.

WARNING: Always disconnect battery ground cable before servicing "high-current" fuses. It is recommended that "high-current" fuses be replaced by a qualified technician.

Fuse & Circuit Breaker Identification

- 1 - 10 Amp (Red)
Left Low Beam
- 2 - 10 Amp (Red)

MAINTENANCE INFORMATION

Article Text (p. 14)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

- Right Low Beam
- 3 - 10 Amp (Red)
Instrument Lights, License Plate Lights
- 4 - 15 Amp (Blue)
Rear Window Wiper, Sliding Roof
- 5 - 15 Amp (Blue)
Windshield & Rear Window Washer, Windshield Wiper
- 6 - 20 Amp (Yellow)
Air Conditioner, Fresh Air Fan
- 7 - 10 Amp (Red)
Right Tail & Side Lights
- 8 - 10 Amp (Red)
Left Tail & Side Lights
- 9 - 20 Amp (Yellow)
Rear Window Defroster, Mirror Heating
- 10 - 15 Amp (Blue)
Foglights
- 11 - 10 Amp (Red)
Left High Beam, High Beam Indicator
- 12 - 10 Amp (Red)
Right High Beam
- 13 - 10 Amp (Red)
Horn, Radiator Fan
- 14 - 15 Amp (Blue)
Back-Up Lights, Electric Mirrors, Heated Washer Jets
- 15 - 10 Amp (Red)
Electronic Ignition, Idle Stabilizer,
Deceleration Fuel Shut Off
- 16 - 15 Amp (Blue)
Warning/Indicator Lights, Multi-Function Indicator, Glove Box
Light, Cassette Storage Light, Rear Spoiler Control Unit
- 17 - 10 Amp (Red)
Emergency Flashers, Turn Signals
- 18 - 20 Amp (Yellow)
Fuel Pump, Heated Oxygen Sensor
- 19 - 30 Amp (Green)
Radiator Fan, Air Conditioner
- 20 - 10 Amp (Red)
Brake Lights, Cruise Control
- 21 - 15 Amp (Blue)
Interior Compartment Lights, Cigarette Lighter, Digital Clock
Central Locking System, Rear Spoiler Adjustment
- 22 - 10 Amp (Red)
Radio

Relay & Circuit Breaker Identification

- 1 - A/C Control Module Relay
- 2 - Rear Window Wiper/Washer Relay
- 3 - ECM Power Supply Relay
- 4 - Load Reduction Relay
- 5 - Low Coolant Level

MAINTENANCE INFORMATION

Article Text (p. 15)


1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

- 6 - Emergency Flasher Relay
- 7 - Not Used
- 8 - Washer/Wiper Intermittent Relay
- 9 - Seat Belt Warning Control Module
- 10 - Fog Lamp/Parking Lamp Relay
- 11 - Dual Horn Relay
- 12 - Fuel Pump Relay
- 13 - ABS Hydraulic Pump Relay
- 14 - ABS Relay
- 15 - Radiator After Run Relay
- 16 - Fuel Pump After Run Control Unit
- 17 - Heated Driver Seat Relay
- 18 - Heated Passenger Seat Relay
- 19 - ABS Hydraulic Pump Fuse (30 Amp)
- 20 - ABS Hydraulic Valve Fuse (30 Amp)
- 21 - Power Window Fuse (20 Amp)
- 22 - ABS Valves Fuse (30 Amp)
- 23 - Not Used
- 24 - Not Used



50D11968

Fig. 11: Fuse & Relay Panel ID (1991-92)
Courtesy of Volkswagen United States, Inc.

MAINTENANCE INFORMATION

Article Text (p. 16)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

WARNING: Always disconnect battery ground cable before servicing "high-current fuses. It is recommended that "high-current" fuses be replaced by a qualified technician.

Fuse & Circuit Breaker Identification

- 1 - 10 Amp (Red)
Left Low Beam
- 2 - 10 Amp (Red)
Right Low Beam
- 3 - 10 Amp (Red)
Instrument Lights, License Plate Lights
- 4 - 15 Amp (Blue)
Rear Window Wiper, Sliding Roof
- 5 - 15 Amp (Blue)
Windshield & Rear Window Washer, Windshield Wiper
- 6 - 20 Amp (Yellow)
Air Conditioner, Fresh Air Fan
- 7 - 10 Amp (Red)
Right Tail & Side Lights
- 8 - 10 Amp (Red)
Left Tail & Side Lights
- 9 - 20 Amp (Yellow)
Rear Window Defroster, Mirror Heating
- 10 - 15 Amp (Blue)
Foglights
- 11 - 10 Amp (Red)
Left High Beam, High Beam Indicator
- 12 - 10 Amp (Red)
Right High Beam
- 13 - 10 Amp (Red)
Horn, Radiator Fan
- 14 - 15 Amp (Blue)
Back-Up Lights, Electric Mirrors, Heated Washer Jets
- 15 - 10 Amp (Red)
Electronic Ignition, Idle Stabilizer,
Deceleration Fuel Shut Off
- 16 - 15 Amp (Blue)
Warning/Indicator Lights, Multi-Function Indicator, Glove Box
Light, Cassette Storage Light, Rear Spoiler Control Unit
- 17 - 10 Amp (Red)
Emergency Flashers, Turn Signals
- 18 - 20 Amp (Yellow)
Fuel Pump, Heated Oxygen Sensor
- 19 - 30 Amp (Green)
Radiator Fan, Air Conditioner
- 20 - 10 Amp (Red)
Brake Lights, Cruise Control
- 21 - 15 Amp (Blue)
Dome & Luggage Compartment Lights, Cigarette Lighter, Clock
Central Locking System, Multi-Function Indicator,
Rear Spoiler Adjustment, Engine Diagnostic

MAINTENANCE INFORMATION

Article Text (p. 17)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>


Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

- 22 - 10 Amp (Red)
Radio

Relay & Circuit Breaker Identification

- 1 - A/C Control Module Relay
- 2 - Rear Window Wiper/Washer Relay
- 3 - ECM Power Supply Relay
- 4 - Load Reduction Relay
- 5 - Not Used
- 6 - Emergency Flasher Relay
- 7 - Not Used
- 8 - Washer/Wiper Intermittent Relay
- 9 - Seat Belt Warning Control Module
- 10 - Fog Lamp/Parking Lamp Relay
- 11 - Dual Horn Relay
- 12 - Fuel Pump Relay
- 13 - ABS Hydraulic Pump Relay
- 14 - ABS Relay
- 15 - Radiator After Run Relay
- 16 - Fuel Pump After Run Control Unit
- 17 - Heated Driver Seat Relay
- 18 - Heated Passenger Seat Relay
- 19 - ABS Hydraulic Pump Fuse (30 Amp)
- 20 - ABS Hydraulic Valve Fuse (30 Amp)
- 21 - Power Window Fuse (20 Amp)
- 22 - ABS Valves Fuse (30 Amp)
- 23 - Automatic Seat Belt System Fuse, S51
- 24 - Not Used



50D11968

Fig. 12: Fuse & Relay Panel ID (1993 - up to January 1993)
Courtesy of Volkswagen United States, Inc.

MAINTENANCE INFORMATION

Article Text (p. 18)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

WARNING: Always disconnect battery ground cable before servicing "high-current fuses. It is recommended that "high-current" fuses be replaced by a qualified technician.

Fuse & Circuit Breaker Identification

- 1 - 10 Amp (Red)
Left Low Beam
- 2 - 10 Amp (Red)
Right Low Beam
- 3 - 10 Amp (Red)
Instrument Lights, License Plate Lights
- 4 - 15 Amp (Blue)
Rear Window Wiper, Sliding Roof
- 5 - 15 Amp (Blue)
Windshield & Rear Window Washer, Windshield Wiper
- 6 - 20 Amp (Yellow)
Air Conditioner, Fresh Air Fan
- 7 - 10 Amp (Red)
Right Tail & Side Lights
- 8 - 10 Amp (Red)
Left Tail & Side Lights
- 9 - 20 Amp (Yellow)
Rear Window Defroster, Mirror Heating
- 10 - 15 Amp (Blue)
Foglights
- 11 - 10 Amp (Red)
Left High Beam, High Beam Indicator
- 12 - 10 Amp (Red)
Right High Beam
- 13 - 10 Amp (Red)
Horn, Radiator Fan
- 14 - 15 Amp (Blue)
Back-Up Lights, Electric Mirrors, Heated Washer Jets
- 15 - 10 Amp (Red)
Crankcase Ventilation Heating Element
- 16 - 15 Amp (Blue)
Warning/Indicator Lights, Multi-Function Indicator, Glove Box Light, Cassette Storage Light, Rear Spoiler Control Unit
- 17 - 10 Amp (Red)
Emergency Flashers, Turn Signals
- 18 - 20 Amp (Yellow)
Fuel Pump, Heated Oxygen Sensor Control
- 19 - 30 Amp (Green)
Radiator Fan, Air Conditioner
- 20 - 10 Amp (Red)
Brake Lights, Cruise Control
- 21 - 15 Amp (Blue)
Dome & Luggage Compartment Lights, Cigarette Lighter, Clock Central Locking System, Multi-Function Indicator, Rear Spoiler Adjustment
- 22 - 10 Amp (Red)

MAINTENANCE INFORMATION

Article Text (p. 19)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>


Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

Radio

Relay & Circuit Breaker Identification

- 1 - A/C Control Module Relay
- 2 - Rear Window Wiper/Washer Relay
- 3 - ECM Power Supply Relay
- 4 - Load Reduction Relay
- 5 - Not Used
- 6 - Emergency Flasher Relay
- 7 - Headlight Washer Relay
- 8 - Washer/Wiper Intermittent Relay
- 9 - Seat Belt Warning Control Module
- 10 - Fog Lamp/Parking Lamp Relay
- 11 - Dual Horn Relay
- 12 - Fuel Pump Relay
- 13 - ABS Hydraulic Pump Relay
- 14 - ABS Relay
- 15 - Not Used
- 16 - Not Used
- 17 - Not Used
- 18 - Power Seat Fuse
- 19 - ABS Hydraulic Pump Fuse
- 20 - ABS Hydraulic Valve Fuse
- 21 - Not Used
- 22 - Power Window Circuit Breaker
- 23 - Fuse, S51
- 24 - Not Used



50D11968

Fig. 13: Fuse & Relay Panel ID (1993 - from January 1993-94)
Courtesy of Volkswagen United States, Inc.

MAINTENANCE INFORMATION

Article Text (p. 20)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

WARNING: Always disconnect battery ground cable before servicing "high-current fuses. It is recommended that "high-current" fuses be replaced by a qualified technician.

Fuse & Circuit Breaker Identification

- 1 - 10 Amp (Red)
Left Low Beam
- 2 - 10 Amp (Red)
Right Low Beam
- 3 - 10 Amp (Red)
Instrument Lights, License Plate Lights
- 4 - 15 Amp (Blue)
Rear Window Wiper, Sliding Roof
- 5 - 15 Amp (Blue)
Windshield & Rear Window Washer, Windshield Wiper
- 6 - 20 Amp (Yellow)
Air Conditioner, Fresh Air Fan
- 7 - 10 Amp (Red)
Right Tail & Side Lights
- 8 - 10 Amp (Red)
Left Tail & Side Lights
- 9 - 20 Amp (Yellow)
Rear Window Defroster, Mirror Heating
- 10 - 15 Amp (Blue)
Foglights
- 11 - 10 Amp (Red)
Left High Beam, High Beam Indicator
- 12 - 10 Amp (Red)
Right High Beam
- 13 - 10 Amp (Red)
Horn, Radiator Fan
- 14 - 15 Amp (Blue)
Back-Up Lights, Electric Mirrors, Heated Washer Jets
- 15 - 10 Amp (Red)
Crankcase Ventilation Heating Element
- 16 - 15 Amp (Blue)
Warning/Indicator Lights, Multi-Function Indicator, Glove Box Light, Cassette Storage Light, Rear Spoiler Control Unit
- 17 - 10 Amp (Red)
Emergency Flashers, Turn Signals
- 18 - 20 Amp (Yellow)
Fuel Pump, Heated Oxygen Sensor
- 19 - 30 Amp (Green)
Radiator Fan, Air Conditioner
- 20 - 10 Amp (Red)
Brake Lights, Cruise Control
- 21 - 15 Amp (Blue)
Dome & Luggage Compartment Lights, Cigarette Lighter, Clock Central Locking System, Multi-Function Indicator, Rear Spoiler Adjustment
- 22 - 10 Amp (Red)

MAINTENANCE INFORMATION

Article Text (p. 21)

1993 Volkswagen Corrado

For Volkswagen Technical Site: <http://vw.belcom.ru>

Copyright © 1998 Mitchell Repair Information Company, LLC

Wednesday, March 22, 2000 09:14PM

Radio

Relay & Circuit Breaker Identification

- 1 - A/C Control Module Relay
- 2 - Rear Window Wiper/Washer Relay
- 3 - ECM Power Supply Relay
- 4 - Load Reduction Relay
- 5 - Engine Coolant Level (ECL) Control Module
- 6 - Emergency Flasher Relay
- 7 - Headlight Washer Relay
- 8 - Washer/Wiper Intermittent Relay
- 9 - Seat Belt Warning Control Module
- 10 - Fog Lamp/Parking Lamp Relay
- 11 - Dual Horn Relay
- 12 - Fuel Pump Relay
- 13 - Back-Up Light Fuse (A/T)
- 14 - Coolant After-Run Control Module
- 15 - ABS Hydraulic Pump Relay
- 16 - ABS Relay
- 17 - Not Used
- 18 - Power Seat Fuse
- 19 - A/C Relay
- 20 - Park/Neutral Position (PNP) Relay
- 21 - ABS Hydraulic Pump Fuse/Power Window Circuit Breaker
- 22 - ABS Hydraulic Valve Fuse
- 23 - Cruise Control Fuse/Automatic Shoulder Belt System Fuse
- 24 - Not Used

END OF ARTICLE